

Hydraulic Dump Sub

The Performance Oil Tools, Inc. Hydraulic Dump Sub is used to drain the fluid from the tubing string above an ECP, PCP or Rod Pump.

FEATURES

- Pressure Actuated
- High Flow Area
- Field Adjustable Opening Pressure
- Tubing I.D.
- Coupling O.D.

OPERATION

Determine the required number of shear screws prior to installation. Place the Hydraulic Dump Sub in the tubing string above the pump assembly. Apply pressure to the tubing string to open the Hydraulic Dump Sub when necessary.



Hydraulic Dump Sub

SIZE	THREADS	ID	OD
2-3/8	2-3/8 EU Box X Pin	1.995	3.125
2-7/8	2-7/8 EU Box X Pin	2.441	3.750
3-1/2	3-1/2 EU Box X Pin	2.992	4.500